

Wiser IP Camera Indoor

Device user guide

Information about features and functionality of the device.

10/2021

Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

Table of Contents

Safety information	5
Wiser IP Camera Indoor	6
For your safety	6
About the device	6
Installing the device	6
Pairing the device	6
Configuring the device	8
Changing the device icon	8
Renaming the device	8
Changing the device location	9
Configuring basic function settings	9
Configuring IR night vision	10
Setting offline notification	11
Inserting a micro-SD card	11
Removing the device	12
Using the device	12
Using private mode	13
Using patrol mode	13
Detection alarm setting	14
Playback	15
Creating a moment	17
Creating an automation	20
LED Indication	24
Troubleshooting	24
Technical Data	24

Safety information

Important information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that accompany this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in death or serious injury**.

Failure to follow these instructions will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in death or serious injury**.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in minor or moderate injury**.

NOTICE

NOTICE is used to address practices not related to physical injury.

Wiser IP Camera Indoor



CCT723319

For your safety

NOTICE

RISK OF DAMAGE TO DEVICE

Always operate the product in compliance with the specified technical data.

Failure to follow these instructions can result in equipment damage.

About the device

The Wiser IP Camera Indoor (hereinafter referred to as **IP Camera**) is a Wi-Fi® operated device that is used to monitor sensitive areas of your home. You can install the IP camera in all directions, e.g. at the ceiling or just put it on a table. The IP camera can be triggered by other Wiser devices.

Advantages of using an IP camera:

- Increases your overall safety
- High resolution recording
- Provides 340° view of the surrounding
- Infrared night vision for low light recording

NOTE: Users are solely responsible for adhering to applicable privacy laws (e.g. the GDPR, Article 5). Users must ensure that guarantees are taken to avoid any misuse of equipment for surveillance or entirely different and unexpected purposes than intended.

Installing the device

Refer to the installation instruction supplied with this product.
See Wiser IP Camera Indoor.

Pairing the device

Using the Wiser app, pair your device with the local Wi-Fi network to register on cloud to access and control the device.

Before you pair the device, download the Wiser app to your mobile device.
Follow the steps to pair the device:


1. On the **Home** page, tap + icon and tap  .

2. Select the **Wi-Fi network**, enter the **Password (A)** and tap **Next**.

NOTE: Make sure to select 2.4 GHz network.




3. Plug-in the power cable to a power supply to power On the device.




Make sure that the LED blinks red.

4. In the Wiser app, select **Confirm that the LED is blinking red (B)** and tap **Start Configuration**.



5. Wait for a few seconds until the LED blinks green and becomes stable.

The green LED on the IP camera shows that it is successfully connected to the Wi-Fi network and ready to use.




6. After the device is connected, tap **Done**.

Configuring the device

Changing the device icon

Using the Wiser app, you can change the icon of the device. Follow the steps to change the device icon:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon and tap **Settings** > .
3. Tap **Icon** to view the menu.
4. In the slide-up menu, select any one of the following (A):
 - Take photo - Allows you to take a photo from the mobile camera
 - Select from Icon Library - Allows you to select an icon from the app library
 - Select from Album - Allows you to select photo from the mobile gallery



5. Tap on the required photo/icon to change the icon.


Renaming the device

Using the Wiser app, you can rename your device for easy identification.

Follow the steps to rename the device:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon and tap **Settings** > .

3. Tap **Name**, enter the name (A) and tap **Save**.




Changing the device location

Using the Wiser app, you can change the location of the device.

Follow the steps to change the device location:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon and tap **Settings** > .
3. Tap **Location**, select any location from the list (A) and tap **Save**.



Configuring basic function settings

Using the Wiser app, you can configure the following features:

Flip screen

Enabling the **Flip screen** will turn the screen upside down on the live view on control panel.

Follow the steps to enable the Flip screen:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon and tap **Settings** > **Basic function settings**.
3. Tap the toggle switch (A) to enable the **Flip screen**.

Time watermark

Enabling the **Time watermark** displays the date and time on the live view on control panel.

Follow the steps to enable the Time watermark:

1. On the **Home** page, tap **All devices > IP Camera Indoor**.
2. Tap  icon and tap **Settings > Basic function settings**.
3. Tap the toggle switch (B) to enable the **Time watermark**.

Talk mode

Using the Talk mode, you can make one-way or two-way communication with the receiver.

Tap **Talk mode** (C) and select one of the options:


- One-way communication - Tap and hold to send a voice message, the other party can receive it and then reply to you with a voice message
- Two-way talk - You and the other party can talk at the same time

Camera calibration

You can use Camera calibration feature to check if the camera is covering wider angle of the view.

Tap **Camera calibration** (D) and confirm the calibration process.

NOTE: The IP camera will turn automatically during the process. It might take 25 seconds to do the calibration.




Configuring IR night vision

The infrared LEDs in the camera allows you to see and record a clear black and white video/image in the dark.

Follow the steps to configure the IR night vision:

1. On the **Home** page, tap **All devices > IP Camera Indoor**.
2. Tap  icon and tap **Settings > IR night vision**.


3. Select any one of the following options:
 - Auto - Turns On/Off automatically when the environmental light is below/above a certain threshold of the lux level
 - Off - Turns Off the IR night vision at all times
 - On - Turns On the IR night vision at all times



Setting offline notification

Using the wiser app, you can receive a notification when the IP camera is offline. Follow the steps to turn on the Offline notification:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon and tap **Settings**.
3. Tap the toggle switch (A) to turn On the **Offline notification** and tap **Confirm**.



Inserting a micro-SD card

The micro-SD card is inserted in the device to store the recording.

NOTE: The micro-SD card has to be inserted before you power On the device. If the device is already in On state, then switch Off the device to insert the micro-SD card.

Follow the steps to insert a micro-SD card:

1. Move the camera up to see the micro-SD card slot.
 - TIP:** If the IP camera is already in use, then use  icon on the control panel to move the camera up.
2. Insert a micro-SD card in the slot.

3. Move the camera back to its initial position.

Once the micro-SD card is inserted, you can configure the playback settings, page 15.


NOTE: A maximum of 128 GB SDHC and SDXC micro-SD cards with FAT32 format are supported.



Removing the device

Using the Wiser app, you can remove a device from the device list. Follow the steps to remove the device:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon and tap **Settings**.
3. Tap **Remove device (A)** and tap **Confirm**.



TIP: Alternatively, you can long tap on the **IP Camera Indoor** on the home page to remove the device.

NOTE:

- Removing the device will reset the device. The LED starts blinking red indicating that the device is ready to pair with another network.
- If there is a problem while pairing, refer to troubleshooting, page 24 the device.

Using the device

Using the control panel of the **IP Camera**, you can see live video of the indoors on the display screen and includes the following features:

	Enables audio of the live video
	Makes the video fullscreen
	Moves the camera in four directions (up, down, right, left)
	Takes screenshot of the live view
	Lets you communicate with a person near the device
	Records the live view

NOTE:


- To view the saved screenshot/recording, tap  > **Album**.
- To view the notification/alarm messages, tap  > **Message**.
- To review the recordings using playback feature, refer to **Playback**, page 15.

Using private mode

The Private Mode allows you to turn off the live view, thereby disabling all the other features on the control panel for all users connected to the same Zigbee network. Using this mode, the user is able to stay confidential during private moments.

Follow the steps to turn On the private mode:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon > **Settings**.
3. Tap the toggle switch (A) to turn On the **Private Mode**.




Using patrol mode

The patrol mode allows you to set up movements for camera to scan a large area by rotating the camera in a single continuous path automatically.

Follow the steps to turn On the patrol mode:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon > **Settings**.

3. Tap the toggle switch to turn On the **Patrol mode**.



Detection alarm setting

The motion detection function enables the IP camera to detect motion at the surveillance area and sends notification on the Wiser app.

Follow the steps to enable the motion detection:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon and tap **Settings** > **Detection alarm settings**.
3. Tap the toggle switch (A) to turn On the **Motion detection alarm**.

Alarm sensitivity level

Using the Wiser app, you can adjust the sensitivity level of your motion detector.

Tap **Alarm sensitivity level** (B) and select any one of the following levels:

– Low

– Medium

– High


NOTE: The high sensitivity level detects the slightest movement and triggers an alarm.

Motion tracking

Enabling the Motion tracking allows the IP camera to detect the motion and automatically move the camera in the direction of the motion.

Tap the toggle switch (C) to enable the **Motion tracking**.


NOTE: The camera will only move in left and right directions.



Scheduling detection alarm

Using the Wiser app, you can add a schedule that allows you to turn off/on motion detection automatically based on your needs. Follow the steps to schedule the motion detection:

1. On the **Home** page, tap **All devices > IP Camera Indoor**.
2. Tap  icon and tap **Settings > Detection alarm settings > Schedule**.
3. Tap **Add schedule** and set the time (A).
4. Tap **Repeat** (B) and select the days you want the schedule to repeat.
5. Tap **Note** (C), enter the note and tap **Confirm**.
6. Tap the toggle switch (D) to turn On the **Notification** for the schedule.
7. Tap **Motion detection** (E), select one of the options:
 - On - Turns On the motion detection on the scheduled time
 - Off - Turns Off the motion detection on the scheduled time




8. Tap **Save**.

Playback

Using the Wiser app, you can review the recording whenever you want with the Playback feature.

NOTE: You need to insert a micro-SD card, page 11 (max 128 GB) to use the playback feature.

The control panel of the playback consists of:

	Select the recording date and time
	Click screenshot of the video
	Pause/play the recording
	Record the video

NOTE:

- A display screen on the control panel shows the previous recordings.
- The screenshot/recording will be saved in the album.

Storage settings


Follow the steps to change the playback settings:

1. On the **Home** page, tap **All devices > IP Camera Indoor**.
2. Tap  icon and tap **Settings > Storage Settings**.
3. In the **Storage Settings** section, tap the toggle switch (A) to enable the **Local recording**.

NOTE: The recording will be saved to the micro-SD card.

4. Tap **Recording mode** (B) and select one of the options:
 - Event recording - Records only when there is a motion detection
 - Non-stop - Records continuously for 24 hours
5. Tap **Format** (C) to format the inserted micro-SD card.

NOTE: This will delete all the data stored on the micro-SD card.




Scheduling playback

Using the Wiser app, you can add a schedule that allows you to turn off/on recording automatically based on your needs.

Follow the steps to schedule the recording:

1. On the **Home** page, tap **All devices** > **IP Camera Indoor**.
2. Tap  icon and tap **Settings** > **Storage Settings** > **Schedule**.
3. Tap **Add schedule** and set the time (A).
4. Tap **Repeat** (B) and select the days you want the schedule to repeat.
5. Tap **Note** (C), enter the note and tap **Confirm**.
6. Tap the toggle switch (D) to turn On the **Notification** for the schedule.
7. Tap **Local recording** (E), select one of the options:
 - On - Turns On the recording on the scheduled time
 - Off - Turns Off the recording on the scheduled time

NOTE: The recording will be saved to the micro-SD card.



8. Tap **Save**.

Creating a moment


A Moment allows you to group multiple actions that are usually done together. Using the Wiser app, you can create moments based on your needs (such as movie night).

Follow the steps to create a moment:

1. On the **Home** page, tap  icon.
2. Go to **Moment** > **+** icon to create a moment.

3. Tap **Edit name**, enter the name of the moment (A) and tap **Save**.

TIP: You can choose the cover image that best represents your moment by tapping  icon.




4. In the **Action** section, tap **Add task** (B) to open the slide-up menu.


5. In the **Add task** menu, you can do either or all of the following actions (C):

- Run the device - Select the devices that you want in a moment
- Delay - Set the delay time

NOTE: You can add one or more actions using  icon.



6. Tap **Run the device > IP Camera Indoor** to select either or all of the functions to add in the moment:
 - Private Mode - Turn On/Off the private mode (D)
 - Recording - Turn On/Off the recording (E)
 - Mode - Select the type of recording (F)
 - Auto-patrol Switch - Turn On/Off the patrol mode (G)




7. Once all the actions are set, tap **Save**.

Editing a moment

Follow the steps to edit a moment:


1. On the **Moment** tab, locate the moment you want to edit and tap ●●● icon.
2. On the **Edit** page, you can tap each item (such as dimmer, shutter, delay, etc.) to change the settings and tap **Save**.



Deleting a moment

Follow the steps to delete a moment:

1. On the **Moment** tab, locate the moment that you want to delete and tap **⋮** icon.
2. Tap **Delete** (A).




Creating an automation

An automation allows you to group multiple actions that are usually done together, triggered automatically or at scheduled times. By using the Wiser app, you can create automations based on your needs.


Follow the steps to create an automation:

1. On the **Home** page, tap the **☰** icon.
2. Go to **Automation** > **+** icon to create an automation.
3. Tap **Edit name**, enter the name of the automation (A) and tap **Save**.

TIP: You can choose the cover image that best represents your automation by tapping  icon.




4. Tap **Any condition is met** to select any one of the condition type (B):
 - All conditions are met - The automation is triggered when all the conditions are met
 - Any condition is met - The automation is triggered when at least one condition is met



5. Tap **Add Condition** to open the slide-up menu.
6. In the **Add Condition** menu, you can do either or all of the following options (C):
 - When weather changes - Select the various weather settings
 - Schedule - Set the time and day
 - When device status changes - Select the device and it's function

Note: You can add one or more conditions using  icon.




7. Tap **When device status changes > Window/Door Sensor > Open**.

NOTE: : This is an example of an automation to turn On the Auto-patrol mode when the Window/Door is Open.

8. Tap **Add task** to open the slide-up menu.


9. In the **Add task** menu, you can do either or all of the following options (D):
- Run the device - Select the devices that you want to be triggered
 - Enable or disable Automation - Select the automation that you want to enable or disable
 - Send notification - Turn On notification for the automation
 - Delay - Set the delay time

NOTE: You can add one or more actions using  icon.




10. Tap **Run the device** > **IP Camera Indoor** > **Auto-patrol Switch**

11. Select **On** and tap **Save**.



12. Tap on Effective period to set the time range for the automation. You can select any one of the following (E):
 - All-day - 24 hours
 - Daytime - From sunrise to sunset
 - Night - From sunset to sunrise
 - Custom - User defined time period




13. Once all the actions and conditions are set, tap **Save**.
Once the automation is saved, it is visible on the **Automation** tab. You can tap the toggle switch on the automation to enable it.

Editing an automation

Follow the steps to edit an automation:

1. On the **Automation** tab, locate the automation you want to edit and tap ●●● icon.
2. On the **Edit** page, you can tap each item (such as dimmer, shutter, delay, etc.) to change the settings and tap **Save**.



Deleting an automation

Follow the steps to delete an automation:

1. On the **Automation** tab, locate the automation you want to delete and tap ●●● icon.

2. Tap **Delete** (A).



LED Indication

User Action	LED Indication
Plug-in the power cable to power on the device	
During the pairing process	
When the pairing process is complete	
While viewing live view on the control panel	

Troubleshooting

Error	Possible cause	Solution
The device is not ready to pair after the device is removed from the app.	The device is not reset correctly.	Long press the reset button for 3 seconds located on the back of the device to reset the device.
The device does not respond. Check demerit points and retry.	Wrong Wi-Fi credentials are entered during the pairing process. NOTE: You must log into 2.4 GHz network.	

Technical Data

Nominal voltage	AC 100–240 V, 50/60 Hz
Power supply	DC 5 V, 2 A
Power consumption	max. 10 W
Ambient temperature	-10 °C to 45°C
Operating humidity	< 95% RH
Operating frequency	2405 – 2480 MHz
Max. radio-frequency power transmitted	< 100 mW

Wi-Fi® standard	IEEE 802.11 b/g/n 2.4 GHz
Wi-Fi® security	WPA-PSK/WPA2-PSK
Channel bandwidth	Support 20/40 MHz
Data security	AES128
Resolution	1080p
Wide angle lens	80° horizontally 40° vertically
IR range	7 m
Pan angle	0° to 340°
Tilt angle	-75° to 75°
Local storage support	Micro SD card, max. 128 GB SDHC and SDXC type micro-SD cards with FAT32 format are supported

Compliance

Compliance information for Green Premium products

Find and download comprehensive information about Green Premium products, including RoHS compliance and REACH declarations as well as Product Environmental Profile (PEP) and End-of-Life instructions (EOLI).

General information about Green Premium products

Click the link below to read about Schneider Electric's Green Premium product strategy.

<https://www.schneider-electric.com/en/work/support/green-premium/>

Find compliance information for a Green Premium product

Click the link below to search for a product's compliance information (RoHS, REACH, PEP and EOLI).

NOTE: You will need the product reference number or product range to perform the search.

<https://www.reach.schneider-electric.com/CheckProduct.aspx?cskey=ot7n66yt63o1xbflyfj>

Trademarks

This guide makes reference to system and brand names that are trademarks of their relevant owners.

- Zigbee® is a registered trademark of the Connectivity Standards Alliance.
- Apple® and App Store® are brand names or registered trademarks of Apple Inc.
- Google Play™ Store and Android™ are brand names or registered trademarks of Google Inc.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.
- Wiser™ is a trademark and the property of Schneider Electric, its subsidiaries and affiliated companies.

Other brands and registered trademarks are the property of their respective owners.

Schneider Electric
35 rue Joseph Monier
92500 Rueil Malmaison
France

+ 33 (0) 1 41 29 70 00

www.se.com

As standards, specifications, and design change from time to time,
please ask for confirmation of the information given in this publication.

© 2021 – Schneider Electric. All rights reserved.

Device user guide_00